

NEO

Quick Start Guide



mPower Electronics Inc.
3046 Scott Blvd. Santa Clara, CA 95054
www.mpowerinc.com
info@mpowerinc.com

PN: M011-4011-000

v1.0

WARNINGS

Read Before Operating

The NEO's User's Guide must be carefully read by all individuals who have or will have the responsibility of using, maintaining or servicing this product. The product will perform as designed only if it is used, maintained and serviced in accordance with the manufacturer's instructions.

Caution

- Change battery only in an area known to be non-hazardous.
- Use only mPower's battery pack PN: M011-3002-000.

Attention

- Changez la batterie uniquement dans une zone connue pour être non dangereuse.
- Utiliser uniquement la batterie mPower PN: M011-3002-000.

1

Warning

- Never operate the monitor when the cover is removed.
- Remove the monitor cover only in area known to be non-hazardous.
- Use only mPower's sensor and accessories. Substitution of components will impair suitability for intrinsic safety and void warranty.
- It is recommended to bump test with a known concentration gas to confirm the instrument is functioning properly before use.
- For maximum safety, the accuracy of the instrument should be checked by exposing it to a known concentration calibration gas before each day's use.
- Ensure that the gas inlet is not blocked.
- When replacing batteries, dispose of old ones properly.
- To achieve the optimal test results, it is recommended to preheat the unit for 2 minutes after entering the test interface
- Make sure that the water-trap filter is clean and replaced in time.
- Don't remove the sensor. Zero and span calibration is required once the sensor is moved.
- Before use, ensure that the ESD film on the display is not damaged or peeling.


Avertissement

- N'utilisez jamais le moniteur lorsque le couvercle est enlevé.
- Retirer le couvercle du moniteur et la batterie uniquement dans une zone connue comme non dangereuse.
- La substitution de composants compromettra l'aptitude à la sécurité intrinsèque et annulera la garantie.
- Il est recommandé de tester avec un gaz de concentration connu pour confirmer que l'instrument fonctionne correctement avant de l'utiliser.
- Avant de l'utiliser, assurez-vous que le film ESD sur l'écran n'est pas endommagé ou épluché.

2

User Interface

The user interface has four-key operation, one big LCD with LED backlight, four red alarm LEDs, and one buzzer.



3

Turning the Unit On

Press and hold the Down Key for 3 seconds, until the buzzer beeps and the red LED flashes. After a warm up and self-test sequence, the unit enters normal reading mode, showing real time gas concentrations.

Turning the Unit Off

In normal reading mode, press and hold the Down Key for a 5-second count down, until "Unit Off" is displayed.

Charging

Always fully charge the battery before use. Plug charger to the bottom of MP18X. Unit LCD will show charge status. While charging, the LCD displays a battery icon cycle from empty to full. When the battery is fully charged, the LCD displays a full battery.

Water-trap Filter

Water-trap filters (P/N: M490-0005-010) are used to protect the sensor from dust and aerosols in dirty environments. The filter should be twisted on to the gas inlet before the instrument is used replaced once its surface is dirty.

4


Testing the Alarms

Important! Test the alarms prior to performing a bump or span calibration test. If any alarm does not respond, check the Alarm Settings in Config Mode to make sure all alarms are enabled (Config Mode → Alm Setting → Alarm Settings → Both Enabled). If any alarms are enabled but are not functional, do not use the instrument.

Under normal operation mode and non-alarm conditions, the buzzer, LED and backlight can be tested anytime by pressing the Right Key once.

Normal Mode

After warm-up is complete, the unit enters normal reading mode and displays the instantaneous gas concentration continuously.



Other values like STEL, TWA, and temperature, etc. can be checked by pressing the Up/Down Key to cycle through these screens one by one.

5


Configuration Mode

In Config Mode, the user can perform a sensor calibration, change the alarm limits and set up other parameters.

Enter/Exit Config Mode

Press and hold the Up and Down Keys together for 3 seconds, to enter Config Mode.

- The Config Mode is password protected.
- The default password is "0000".
- After all four digits are entered, move the cursor to ✓ and press the Up Key to enter config mode.
- Press the Left Key to exit Config Mode.



6

Config Mode Menu


- Calibration:
Zero Calib, Span Calib, Set Cal.Gas, Set Span Value, Set Span 2 Value
- Meas.:
Measurement Unit, Measurement Gas
- Alm Setting:
Alarm Limits, Alarm Mode, Alarm Settings, Comfort Beep, Man Down Alarm
- Datalog:
Clear Datalog, Interval
- Mnt (Monitor) Setup:
Data & Time, Display, Pump Speed, Pump Stall, 3-Point Cal., Rolling Graph, Real Time Data, Language, Self-Zeroing
- Wireless:
Radio On/Off

7

Zero Calibration

Zero calibration is to get the baseline for the sensor and is done in normal fresh air or other clean air source.

- To enter fresh air calibration:
Config Mode → Calibration → Zero Calib.
- To start fresh air calibration:
Press the Right Key and a count-down timer starts. When the count-down is finished, “Pass” or “Fail” will be displayed. To abort the zero calibration use the Left Key during count down.




8

Span Calibration

Span calibration is to get the metric of the sensor to the gas, it is done with a known concentration gas.

- To enter span calibration:
Config Mode → Calibration → Span Calib
- To start span calibration:
Apply Gas → Start Calibration → Wait Count-down Finish → Get Result.



Maintenance and Service

For battery, sensor replacement and other maintenance refer to the User Manual or contact mPower’s service department.

Year of Manufacture

The year of manufacture can be identified by the fifth and sixth digits of the instrument serial number. For example, 16 indicates that the unit was made in 2016.

9