



8406 Benjamin Rd. · Suite J · Tampa, FL 33634 USA · Telephone: 813-249-5888 · Toll Free: 877-312-2333
Fax: 813-249-0188 · Toll Free: 877-312-2444 · Web: www.nextteq.com · Email: info@nextteq.com

Nextteq Irritant Smoke Tubes for Respirator Fit Testing SENSITIVITY CHECK PROTOCOL

Introduction

This protocol is provided to you to be used in conjunction with normal irritant smoke fit test procedures as outlined in OSHA 29 CFR 1910.134. The user is responsible for determining whether the test protocol, product, or component is fit for a particular purpose and suitable for the user's method of use or application and suitable for the test subject. Nextteq highly recommends that you follow this Sensitivity Check protocol when performing the sensitivity check for irritant smoke qualitative fit testing required by OSHA 29 CFR 1910.134.

Warnings

1. Read, understand, and comply with all labels, Gastec and Nextteq warnings, instructions, and other literature accompanying the Nextteq Irritant Smoke Tubes for Respirator Fit Testing Kit, Gastec Irritant Smoke Tubes, and Nextteq Aspiration Bulb Pump as well as all warnings and instructions incorporated in this protocol, including but not limited to, the Gastec Instructions and Warnings (included in the box of Gastec Irritant Smoke Tubes No. 9501) and the Nextteq Irritant Smoke Tube Kit Manual (P/N 9505) before using the smoke tubes or this protocol.
2. Perform this test protocol and operate the smoke tube and smoke tube pump in strict compliance with Gastec and Nextteq specifications, instructions, and warnings including but not limited to the Gastec Instructions and Warnings (included in the box of Gastec Irritant Smoke Tubes No. 9501) and the Nextteq Irritant Smoke Tube Kit Manual (P/N 9505), as well as the instructions and warnings incorporated in this test protocol.
3. Use this Sensitivity Check test protocol only with a Gastec Irritant Smoke Tube (Part Number 9501) and Nextteq Aspiration Bulb Pump (P/N 9502) or Nextteq One-Way Aspiration Bulb Pump (P/N 90005) as packaged in the Nextteq Irritant Smoke Tubes for Respirator Fit Testing Kit (P/N 9500). Do not use an electronic pump with this Sensitivity Check test protocol.
4. Do not use this Sensitivity Check test protocol unless you are a trained, qualified, technically competent, and professional industrial, commercial, military, or government respirator user/test administrator experienced in generating a small, weak, dilute stream of smoke with an aspiration bulb pump. This test protocol is solely for distribution to, storage by, and use by trained, qualified, technically competent, and professional industrial, commercial, military, or government respirator users/test administrators in compliance with OSHA 29 CFR 1910.134.
5. Do not use this test protocol or a Sensitivity Check for voluntary respirator use.
6. This test is to be conducted only by an experienced, trained, and qualified professional test administrator. The experienced, trained, and qualified professional test administrator shall be able to correctly perform the following:
 - A. Instruct the test subject.
 - B. Demonstrate the techniques for performing the test.
 - C. Inspect, test, calibrate, and operate all test equipment.
 - D. Ensure all test equipment and components are in good working order and are suitable to be used together.
 - E. Generate a small, weak, dilute stream of irritant smoke that is the absolute minimum amount necessary to elicit a response.
 - F. Perform the Sensitivity Check.
 - G. Recognize an invalid test.
7. Prior to commencing the Sensitivity Check:



8406 Benjamin Rd. · Suite J · Tampa, FL 33634 USA · Telephone: 813-249-5888 · Toll Free: 877-312-2333
Fax: 813-249-0188 · Toll Free: 877-312-2444 · Web: www.nextteq.com · Email: info@nextteq.com

- A. The administrator shall ensure the test subject has read, understands, and agrees to comply with all the provisions of this test protocol; all of Gastec and Nextteq specifications, instructions, and warnings; and the test subject's duties and responsibilities as described in OSHA 29 CFR 1910.134.
 - B. The test subject shall be given a description of the test, the test subject's duties and responsibilities, and instructed to minimize his or her exposure to the smoke and to keep his or her eyes tightly shut during the test.
 - C. The test subject shall be instructed to immediately step into fresh, clean air in the event of any exposure or response to irritant smoke.
 - D. The test subject shall be given instructions in and shall correctly demonstrate for an experienced, trained, and qualified professional test administrator:
 - I. The proper method to waft a small, weak, and diluted concentration of smoke toward the test subject by extending his or her arm at full length with the palm up and fingers closed together. The test subject's hand should be extended to the edge of the smoke cloud. If the test subject's arm is not extended at full length, the test subject shall back up until his or her arm is at full length. The test subject should be approximately three feet from the edge of the smoke cloud. The test subject should slowly and very gently wave his or her fingers on one hand in the direction of his or her face.
 - II. The proper method to sample a slight whiff of smoke by taking a small, weak, shallow, and short duration sniff of smoke while immediately stepping away from the smoke into fresh, clean air.
8. Do not use this product for the Sensitivity Check Protocol if any of the following conditions are present:
- A. The test subject has a pre-existing respiratory, cardiovascular, or bronchial medical condition.
 - B. The test subject is under a physician's care for a respiratory, cardiovascular, or bronchial ailment; sinus, nasal or ear infection; or impaired immune system; or asthma.
 - C. The test subject is hypersensitive or allergic to stannic chloride, stannic oxide, hydrogen chloride, tin tetrachloride, tin compounds, or metal chloride.
9. If the test subject does not agree to comply with all Gastec and Nextteq specifications, instructions, and warnings or does not agree to perform all the duties and responsibilities described in OSHA 29 CFR 1910.134, or the test subject cannot correctly demonstrate the correct method to waft the smoke toward the test subject or demonstrate the correct method to sample a slight whiff of smoke, the test subject shall not be fit tested and the Sensitivity Check shall not be performed.
10. The administrator shall not conduct a Sensitivity Check of more than one test subject at a time.
11. The Sensitivity Check shall be conducted in a calm, windless, and well-ventilated area. No form of hood, chamber, or other enclosure is to be used. Do not perform the Sensitivity Check in a confined space or in an area with moving air that may blow the smoke toward the test subject or administrator. In the area where the Sensitivity Check is performed, the ground surface or deck surface or floor surface shall be flat and level, reasonably smooth, and free of holes and obstructions.
12. The administrator shall be careful to recognize that each test subject's sensitivity and response to irritant smoke vary. Sensitivity and response vary based upon size, weight, heredity, health, age, and other factors. Some test subjects may respond to a far greater degree than others to a small amount of irritant smoke. The administrator shall consider the test subject's unique characteristics, including but not limited to, size, weight, heredity, health, allergies, medical history, age, and other relevant factors as well as sensitivity to irritant smoke before generating a small, dilute stream of irritant smoke that is the absolute minimum concentration of irritant smoke necessary to elicit a response from the test subject.



8406 Benjamin Rd. · Suite J · Tampa, FL 33634 USA · Telephone: 813-249-5888 · Toll Free: 877-312-2333
Fax: 813-249-0188 · Toll Free: 877-312-2444 · Web: www.nextteq.com · Email: info@nextteq.com

13. The administrator and the test subject shall take precautions to minimize the test subject's and administrator's exposure to smoke. The test subject shall only be exposed to a small, weak, dilute concentration of smoke that is the absolute minimum necessary to elicit a response.
14. Prior to commencing the Sensitivity Check, the administrator shall instruct the test subject:
 - A. That the smoke is irritating to the eyes, nasal passageway, respiratory tract, and lungs.
 - B. That the test subject's eyes should be tightly closed before he or she wafts the smoke in his or her direction.
 - C. That the test subject's eyes should remain closed until the test subject is free of the irritant smoke.
 - D. That the administrator shall advise the test subject when the test subject is free of the smoke and it is safe for the test subject to open his or her eyes.

Test Protocol

1. Wearing a pair of safety gloves and eye protection, break both ends of the Gastec Irritant Smoke Tube by bending each end in the tube tip breaker hole.
2. Place a black cap on one end of the smoke tube.
3. Pointing the tube end with the black cap away from you, insert the tube into the Nextteq Aspiration Bulb Pump, being careful not to compress the bulb.
4. Confirm you are using the correct aspiration bulb pump for the Sensitivity Check.
5. Immediately before commencing the Sensitivity Check, remove the black cap from the end of the tube.

NOTE: Retain the black cap for later use.

6. Holding the pump at half arm's length away from you, place the protective tube sheath over the jagged end of the smoke tube and aim the tip of the smoke tube away from you and the test subject.
7. Tell the test subject to tightly close his or her eyes.

CAUTION: Prior to compressing the bulb, ensure the smoke tube tip is 36 inches or more away from the test subject's face and NOT aimed in the direction of the test subject's face.

8. Slowly and gently compress the bulb at a controlled, uniform, steady rate until a small, weak, dilute stream of irritant smoke is produced that is the absolute minimum necessary to elicit a response from the test subject being tested.
9. Immediately stop compressing the bulb and release the partially compressed bulb. No additional smoke is to be generated.
10. The test subject shall stand approximately three feet away from the cloud of smoke.
11. The test subject shall extend his or her arm to the edge of the smoke cloud with palm facing upward.
12. Keeping his or her eyes closed, the test subject shall gently and slowly wave a small, dilute portion of the smoke toward his or her breathing zone using the fingertips of his or her outstretched hand.
13. Keeping his or her eyes closed, the test subject shall sample a slight, weak, dilute whiff of smoke by taking a small, weak, shallow, and short duration sniff of smoke.
14. The test subject shall then immediately step away from the smoke into clean, fresh air.



8406 Benjamin Rd. · Suite J · Tampa, FL 33634 USA · Telephone: 813-249-5888 · Toll Free: 877-312-2333
Fax: 813-249-0188 · Toll Free: 877-312-2444 · Web: www.nextteq.com · Email: info@nextteq.com

15. The trained, qualified, professional test administrator shall advise the test subject when the test subject is away from the smoke. The administrator shall then instruct the test subject to open his or her eyes.
16. The irritant smoke should produce an involuntary reaction (cough or sneeze) by the test subject.
17. If the test subject fails to provide a reflex response after an initial Sensitivity Check, then wait until all the smoke has vanished and until the test subject confirms all effects of the smoke have ceased before repeating the Sensitivity Check. Do not perform repeat Sensitivity Checks on the same individual too frequently.
18. If the test subject has not previously been exposed to irritant smoke, the Respirator Fit Test should not be started until the test subject first passes the initial Sensitivity Check.
19. Upon the completion of each Sensitivity Check, if the smoke tube has not been consumed and when testing is complete, the administrator shall, with the smoke tube tip pointed away from the administrator and others, slowly compress the pump bulb. When the pump bulb is fully compressed, place a cap over the exposed end of the smoke tube. Do not remove the aspiration bulb pump. Store the partially consumed smoke tube with the cap affixed to one end and the compressed aspirator bulb pump affixed to the other end of the smoke tube.
20. When the smoke tube is consumed, or is being disposed of prior to being consumed, gently remove the aspirator bulb pump from the smoke tube, being careful not to compress the bulb. Turn the bulb upside down over an appropriate waste receptacle and gently shake the bulb to discard any residual material from the irritant smoke tube. Neutralize and dispose of any residual smoke tube material and the smoke tube in accordance with federal, state, and local regulations and laws.
21. Store the Nextteq Irritant Smoke Tube Kit, the Gastec Irritant Smoke Tubes, and the Nextteq Aspiration Bulb Pump in a safe, secure, dry, cool space away from direct light and out of the reach of children.
22. Do not perform the Sensitivity Check or Respirator Fit Test if you do not understand or are confused about the operation, performance, or use of the Nextteq Irritant Smoke Tube Kit; Gastec Irritant Smoke Tubes; Nextteq Aspiration Bulb Pump; respirator, filter, or associated equipment; the Gastec warnings, specifications, or instructions; the Nextteq warnings, instructions, or specifications; the MSDS; the Respirator Fit Testing Protocol; or the Sensitivity Check Protocol.

IF YOU HAVE ANY QUESTIONS ABOUT THE OPERATION, PERFORMANCE, OR USE OF THE NEXTTEQ IRRITANT SMOKE TUBE KIT, GASTEC IRRITANT SMOKE TUBES, NEXTTEQ ASPIRATION BULB PUMP, THIS TEST PROTOCOL, OR THE GASTEC INSTRUCTIONS OR WARNINGS, NEXTTEQ, LLC CAN BE CONTACTED AT ONE OF THE FOLLOWING TELEPHONE NUMBERS: TOLL FREE 877-312-2333 OR LOCAL NUMBER 813-249-5888.

DISCLAIMER OF WARRANTIES

THE INFORMATION AND RECOMMENDATIONS CONTAINED IN THIS DOCUMENT ARE PROVIDED FREE WITHOUT CHARGE SOLELY FOR USE BY QUALIFIED INDUSTRIAL OR COMMERCIAL USERS AT THEIR DISCRETION AND RISK. READ, UNDERSTAND, AND COMPLY WITH ALL INSTRUCTIONS, WARNINGS, LABELS, AND MANUALS BEFORE USING AND WHILE USING GASTEC OR NEXTTEQ PRODUCTS OR TEST PROTOCOL. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS CONTAINED IN THIS DOCUMENT ARE BASED UPON DATA AND OTHER INFORMATION THAT NEXTTEQ BELIEVES TO BE CORRECT AND COMPLETE AS OF THE DATE ISSUED, BUT THE ACCURACY AND COMPLETENESS THEREOF IS NOT GUARANTEED AND NO WARRANTY OF ANY KIND IS MADE WITH RESPECT TO THIS DOCUMENT, THE INFORMATION, OR RECOMMENDATIONS CONTAINED IN THIS DOCUMENT. THIS INFORMATION IS NOT INTENDED AS A LICENSE TO OPERATE UNDER OR A RECOMMENDATION TO PRACTICE OR TO INFRINGE UPON ANY PATENT, TRADEMARK, TRADE SECRET, OR PROPRIETARY INFORMATION OF NEXTTEQ, THE GASTEC CORPORATION, OR OTHERS COVERING ANY PROCESS, COMPOSITION, MATTER, OR USE. THE USER IS RESPONSIBLE FOR DETERMINING WHETHER THE TEST PROTOCOL, PRODUCT, OR COMPONENT IS FIT FOR A PARTICULAR PURPOSE AND SUITABLE FOR THE USER'S METHOD OF USE OR APPLICATION AND SUITABLE FOR THE TEST SUBJECT. TEST SUBJECT SENSITIVITY TO STANNIC CHLORIDE VARIES. THE SIZE OF DIFFERENT MANUFACTURERS' ASPIRATION BULB PUMPS VARIES. THE PACKING DENSITY AND CHEMICAL PURITY OF DIFFERENT MANUFACTURERS' IRRITANT SMOKE TUBES VARY. THE SKILL AND TRAINING OF TEST ADMINISTRATORS VARY. GIVEN THE VARIETY OF FACTORS THAT CAN AFFECT THE USE AND APPLICATION OF A



8406 Benjamin Rd. · Suite J · Tampa, FL 33634 USA · Telephone: 813-249-5888 · Toll Free: 877-312-2333
Fax: 813-249-0188 · Toll Free: 877-312-2444 · Web: www.nextteq.com · Email: info@nextteq.com

PRODUCT OR COMPONENT, SOME OF WHICH ARE UNIQUELY WITHIN THE USER'S KNOWLEDGE OR CONTROL, IT IS ESSENTIAL THAT THE USER EVALUATE THE PRODUCT OR PROTOCOL OR COMPONENT TO DETERMINE WHETHER THE PRODUCT, PROTOCOL, OR COMPONENT IS FIT FOR A PARTICULAR PURPOSE AND ADDITIONALLY SUITABLE FOR USER'S METHOD OF USE OR APPLICATION OR TEST SUBJECT. NEXTTEQ'S WARRANTY IS SET FORTH IN NEXTTEQ'S TERMS AND CONDITIONS OF SALES MADE BY NEXTTEQ AND ACCEPTED BY BUYER IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED INCLUDING, BUT NOT LIMITED TO, ANY OTHER AFFIRMATION OF FACT, RECOMMENDATION, OR PROMISE THAT RELATES TO THE GOODS, THIS DOCUMENT, INFORMATION, OR RECOMMENDATIONS CONTAINED IN THIS DOCUMENT, OR ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, WHICH ARE EXPRESSLY DISCLAIMED. THIS PRODUCT, PROTOCOL, OR DOCUMENT IS ONLY FOR SALE TO, ONLY FOR USE BY, AND ONLY FOR STORAGE BY A TRAINED, QUALIFIED, TECHNICALLY COMPETENT, AND PROFESSIONAL COMMERCIAL, INDUSTRIAL, MILITARY, OR GOVERNMENT USER. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION SET FORTH IN NEXTTEQ'S TERMS AND CONDITIONS OF SALE. NEXTTEQ SHALL NOT BE LIABLE FOR DIRECT OR INDIRECT CONSEQUENTIAL, INCIDENTAL, STATUTORY, PUNITIVE, OR OTHER DAMAGES OR LOSS RESULTING FROM THE PROPER OR IMPROPER USE OF EITHER THE PRODUCT, THIS PROTOCOL, OR COMPONENT SOLD BY NEXTTEQ OR ANY INFORMATION OR RECOMMENDATION CONTAINED IN THIS DOCUMENT. THIS LIMITATION OF DAMAGES IS INDEPENDENT OF ANY LIMITATION OF REMEDIES PROVISION AND WILL BE ENFORCEABLE EVEN IF A REMEDY FAILS ITS ESSENTIAL PURPOSE. IF THE USER IS CONFUSED ABOUT THE PROPER USE OF THE NEXTTEQ IRRITANT SMOKE TUBE KIT, THE GASTEC IRRITANT SMOKE TUBES, THE NEXTTEQ ASPIRATOR BULB PUMP, ANY INSTRUCTIONS, WARNINGS, LABELS, SPECIFICATIONS, TEST PROTOCOL, MSDS, OR THE MANUAL, THE USER SHOULD IMMEDIATELY CALL NEXTTEQ FOR ASSISTANCE PRIOR TO ATTEMPTING TO USE OR USING THE PRODUCT, THE IRRITANT SMOKE TUBES, THE SMOKE TUBE PUMP, OR THIS SENSITIVITY CHECK TEST PROTOCOL. NEXTTEQ CAN BE CONTACTED AT ONE OF THE FOLLOWING TELEPHONE NUMBERS: TOLL FREE 877-312-2333 OR LOCAL NUMBER 813-249-5888.

LIMITATION OF DAMAGES

THE PARTIES HERETO AGREE THAT BUYER'S SOLE AND EXCLUSIVE DAMAGES FOR SELLER'S BREACH SHALL BE LIMITED TO THE PRICE OF THE GOODS SOLD AND THAT ALL OTHER DAMAGES, INCLUDING BUT NOT LIMITED TO, CONSEQUENTIAL, INCIDENTAL, EXEMPLARY, PUNITIVE, AND STATUTORY DAMAGES ARE EXCLUDED. THE PARTIES FURTHER AGREE THAT THIS LIMITATION OF DAMAGES PROVISION IS INDEPENDENT OF THE LIMITATION OF REMEDIES PROVISION AND WILL BE ENFORCEABLE EVEN IF A REMEDY FAILS ITS ESSENTIAL PURPOSE.

LIMITATION OF REMEDIES

THE PARTIES HERETO AGREE THAT BUYER'S SOLE AND EXCLUSIVE REMEDY AGAINST THE SELLER SHALL BE, AT SELLER'S OPTION, (1) REPAIR OF THE DEFECTIVE GOODS (2) REPLACEMENT OF THE DEFECTIVE GOODS OR (3) REPAYMENT OF THE PURCHASE PRICE OF THE DEFECTIVE GOODS. IF SELLER IS UNABLE TO PROVIDE ANY SELECTED REMEDY, SELLER MAY ELECT TO PROVIDE BUYER WITH ANY REMAINING EXCLUSIVE REMEDY UNTIL ALL EXCLUSIVE REMEDIES HAVE BEEN EXHAUSTED. THE NUMBER OF REMEDIES PROVIDED AND THE ORDER IN WHICH THE REMEDIES ARE PROVIDED SHALL BE DETERMINED SOLELY BY THE SELLER. THIS EXCLUSIVE REMEDY IS ONLY AVAILABLE TO THE BUYER IF BUYER RETURNS THE DEFECTIVE GOODS TO SELLER FOR INSPECTION AND SELLER'S INSPECTION DETERMINES A DEFECT EXISTS AND THAT THE DEFECT WAS NOT CAUSED IN WHOLE OR IN PART BY THE BUYER OR BY ANYONE'S USE, OPERATION, STORAGE, MAINTENANCE, REPAIR, HANDLING, OR TRANSPORTATION OF THE DEFECTIVE GOODS WHICH WAS INCONSISTENT WITH SELLER'S OR THE MANUFACTURER'S SPECIFICATIONS, INSTRUCTIONS, OR WARNINGS.