

Pyridine 5/A

Catalog No 6728651

Standard Measuring Range: 5 ppm
Number of Strokes (n): 20, an additional 5 strokes is taken in clean air after opening the second reagent ampule.
Time for Measurement: about 20 minutes
Standard Deviation: ± 30%
Color Change: white to brown red

Ambient Operation Conditions

Temperature: 10 to 30°C
Absolute Humidity: 3 to 15 mg H₂O/L

Reaction Principle

Pyridine + Aconitic acid + Acetic anhydride ———> brown red reaction product

Cross Sensitivity

Ammonia in the TLV range does not interfere.

Additional Information

Before carrying out the measurement the lower reagent ampule must be broken and the liquid transferred to the indication layer so that it is saturated. After performing 20 pump strokes, the upper reagent ampule must be broken. The granular contents must be shaken out of the broken ampule by gently tapping the side of the tube. The tube must be held vertically with the inlet of the tube up during the 5 additional pump strokes.



Dräger

Manufactured by Draeger Safety

Distributed by AFC International, Inc.

PO Box 894

DeMotte, IN 46310

800.952.3293 • 219.987.6825 • fax 219.987.6826

www.afcintl.com • sales@afcintl.com