

## Dräger X-plore® 6000 Singlefilter Full Face Masks



ST-5425-2005

### Preparation and filter attachment



ST-7818-2006

1 Screw the Dräger X-plore Rd40 filter into the mask body.

### Donning the mask



ST-7822-2006

2 Open straps as far as possible. Direct the mask towards the face.



ST-7835-2006

3 First insert chin into the chinpiece of the mask.



ST-7843-2006

4 Fit harness over the head until the mask is in position.



ST-7853-2006

5 Tighten straps until the mask fits snug and secure. First tighten both neck straps, ...



ST-7859-2006

6 ... then both temple straps and ...



ST-7861-2006

7 ... tighten front strap if necessary.



ST-7876-2006

8 Negative pressure test: Seal respiratory filters with your palm and breathe in until a negative pressure (suction) is generated. Hold your breath for a moment. The negative pressure should be maintained. If not, readjust the face piece and adjust the straps. Repeat test until a successful for check is met.

### Performing seal checks: before every use!

**Warning:** Beards in the sealing area of the mask can cause leaks. Always make sure the mask forms a tight seal and the filter is attached prior to entering a hazardous atmosphere.

This poster is not a replacement for reading and understanding the instructions for use for the subject mask and respective filter cartridge, both of which must be read before using either item! Failure to do so could result in sickness or death!

For further assistance concerning proper use, ask your supervisor or call your local Dräger organization at +49 451 882-0 or +1 800 922 5518.

Distributed by  
AFC International Inc  
PO Box 894  
DeMotte IN 46310  
800.952.3293 • 219.987.6825  
fax 219.987.6826  
sales@afcintl.com • www.afcintl.com