WARRANTY EXCLUSIONS AND LIMITATION OF LIABILITY

IF THE USER DOES NOT ACCEPT THE FOLLOWING TERMS, THE USER SHOULD NOT USE THE CHROMAIR BADGES AND COLOR COMPARATORS.

Seller warrants that, for the lesser of one (1) year or the shelf-life provided on the Seller's product, its packaging or its literature, its products shall conform to the description of such products as provided on the Seller's product, its packaging or its literature. <u>THIS</u> <u>WARRANTY IS EXCLUSIVE, AND SELLER MAKES NO OTHER WARRANTY, EXPRESS</u> <u>OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR</u> <u>FITNESS FOR ANY PARTICULAR PURPOSE</u>. Seller's warranties made in connection with this sale shall not be effective if Seller has determined, in its sole discretion, that Buyer has misused the products in any manner, has failed to use the products in accordance with Seller's written operating instructions, or other instructions furnished by Seller to Buyer.

Seller's sole and exclusive liability and Buyer's exclusive remedy with respect to products to Seller's satisfaction to be defective or nonconforming shall be replacement of such products without charge or refund of the purchase price, in Seller's sole discretion, upon the return of such products in accordance with Seller's instructions. All claims must be brought within one (1) year of shipment, regardless of their nature.

SELLER SHALL NOT IN ANY EVENT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY KIND RESULTING FROM ANY USE OR FAILURE OF THE PRODUCTS, EVEN IF SELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE INCLUDING, WITHOUT LIMITATION, LIABILITY FOR LOSS OF USE, LOSS OF WORK IN PROGRESS, DOWN TIME, LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS, LOSS OF PRODUCTS OF BUYER OR OTHER USE OF ANY LIABILITY OF BUYER TO A THIRD PARTY ON ACCOUNT OF SUCH LOSS, OR FOR ANY LIABOR OR ANY OTHER EXPENSE, DAMAGE OR LOSS OCCASIONED BY SUCH PRODUCT INCLUDING PERSONAL INJURY OR PROPERTY DAMAGE UNLESS SUCH PERSONAL INJURY OR PROPERTY DAMAGE IS CAUSED BY SELLER'S GROSS NEGLIGENCE.

Warning: Keep out of reach of children, if ingested seek medical attention immediately.



2557 Production Road Virginia Beach, VA 23454 Phone: (757) 431-2260 Fax: (757) 216-6209 e-mail: customerservice@morphtec.com

©1997, Morphix Technologies® All rights reserved Publication Number: KM3-12A.9-0606 US Patent Number: 5,364,593



Operating Instructions For Formaldehyde Monitor (Part Number: 380007)

Technical Summary

Physical Specifications:

Dimensions Weight Refrigerated shelf life Color change	10.5 cm x 5.5 cm x 0.25 cm 11 g 1 year yellowish-brown to brown
Sampling Parameters:	
Exposure range for:	
Badge	0.3 - 12 ppm•hr
Badge used with color comparator	0.3 - 40 ppm•hr
Maximum recommended sampling time	2 days
Minimum recommended sampling time	15 minutes
Relative humidity range	30% - 80%
Face velocity range	5 - 150 cm/sec

Face velocity range	5 - 150 CM/Sec
Temperature range	16ºC - 35ºC (61ºF - 95ºF)
Mean coefficient of variation	<u>+</u> 10.23
Bias at ambient conditions	-2.73%
Light effect - UV (direct sunlight)	no effect
Light effect - visible	no effect

Applications:

The ChromAir formaldehyde badge may be used for personnel or area monitoring for exposure times ranging from 15 minutes to 2 days. For higher resolution, the ChromAir formaldehyde badge may be used in conjunction with the ChromAir formaldehdye color comparator (part number: 384001).

Cross Interferences:

Acrolein and the aldehydes that exist in cigarette smoke react with approximately the same sensitivity. It is impossible to monitor formaldehyde in the presence of cigarette smoke. The ChromAir formaldehyde badge was treated in atmospheres containing at least two times the OSHA PEL for the following substances: alcohols (methanol and ethanol), aromatic hydrocarbons (benzene, toluene and xylene), halogenated hydrocarbons (chloroform, methylene chloride and carbon tetrachloride), ammonia, carbon monoxide, chlorine, glutaraldehyde, hydrogen sulfide, nitrogen dioxide, phenol and sulfur dioxide. These substances showed no effect on the performance of the ChromAir formaldehyde badge. No other interferences are known.

Öã dãa čo å Áa ^ KOEZÓÁQ, co ¦}æaā[}ædÁQ, &ÁÁÚUÁÓ[¢Á, JIÁÁÖ^T [co ĤÁQe Á ÎHF€ÁÁ È €ÈÍGÈHGJHÁÁGFJÈÌÌÏÈÌGÍÁÁæ¢ÁGFJÈÌÌÏÈÌGÎÁÁ æ†^•ÁO æ&8a]dÈ&[{

Introduction

Formaldehyde is a colorless gas with a pungent, suffocating odor. It is a potent irritant to eyes, nose and throat. The most common effects of low level formaldehyde inhalation are eye, nose and upper respiratory irritation. Chronic symptoms of exposure are itching eyes, dry and sore throat, and possible difficulty in sleeping and unusual thirst after awakening. OSHA exposure limit for formaldehyde is 0.75 ppm (TWA). NIOSH exposure limit is 0.016 ppm (TWA). NIOSH also recommends that formaldehyde be handled as a potential occupational carcinogen in the workplace.

Formaldehyde workplace exposure occurs because of its extensive use as an industrial chemical in the manufacturing of resins for adhesives, plastics, coatings and fabrics. Additional exposure to formaldehyde emissions comes from its use as a fumigant and sterilant. The major source of atmospheric discharge of formaldehyde is from combustion processes, specifically from the photo-oxidation of hydrocarbons in auto emissions.

Principle of Operation

The ChromAir passive monitor is a patented direct-read autogenic exposimeter. The device is constructed from six cells attached on one side to a flat indicator layer and on the other side to a series of different diffusive resistances. Formaldehyde gas diffuses to the cells through the different diffusive resistances and reacts with the indicator layer, producing color change from yellowish-brown to brown. The color produced on the indicator layer is a direct measure of the exposure dose. Visual color is achieved by observing the formation of the brown threshold color on the individual cell and reading the corresponding exposure dose.

Operating Instructions

- 1. Remove the pouch from refrigerator and allow it to warm to room temperature.
- 2. Remove the badge from its protective pouch.
- 3. Enter all pertinent information on the I.D. label before monitoring is started (i.e. name, location, date and start time).
- 4. For personnel monitoring, attach the badge near the user's breathing zone (i.e. collar) with the front side exposed to the surrounding atmosphere.
- 5. For area monitoring, attach the badge to a stand and mount in a centralized area with the front side exposed to the surrounding atmosphere.
- 6. Check the back side of the badge periodically to determine the exposure dose (ppm•hr).
- 7. To read the badge, locate the highest level cell with brown threshold color.
- 8. To obtain the average concentration (ppm) in the surrounding atmosphere, divide the exposure dose (ppm•hr) by the exposure time in hours. EXAMPLE: If the sampling time is 2 hours and the badge reads 2 ppm•hr, the average concentration is determined by:
 - $\frac{2 \text{ ppm+hr}}{2 \text{ hr}}$ Therefore the average concentration is 1 ppm.

Storage

The ChromAir formaldehyde monitor should be refrigerated in its sealed bag at all times.

Benefits

- Accurate Measurements: The ChromAir formaldehyde monitor is designed to react selectively with formaldehyde with minimum interference from other substances. The unique design of the monitor minimizes the effects of different humidities, temperatures and air velocities on the accuracy of measurements.
- 2. Applications: The ChromAir monitor may be used for personnel screening and for area monitoring or area mapping.
- 3. Ease of Use: The ChromAir monitor is a direct-read device that gives immediate, on-site results. Use of this device requires minimum training.
- 4. Cost Effective: The ChromAir formaldehyde monitor offers the user the most inexpensive air sampling solution available.

Other Available Monitors

1. ChromAir Badges: Acetone

Carbon monoxide

Ammonia

Chlorine

Ethanol Glutaraldehyde Hydrogen sulfide Mercury Methanol Methyl ethyl ketone Methyl isobutyl ketone Ozone

2. ChromAir Color Comparators: Ammonia Hydrogen sulfide Carbon monoxide Mercury Chlorine

If you require ChromAir monitors for a chemical hazard not listed, please contact Morphix Technologies® for a free compound consultation at (800) 808-2234.