

Dräger X-plore® 3300/3500 Twinfilter Half Masks



Preparation and filter attachment



1 Attach the bayonet filters. The filter and mask body are marked to help you.



2 Turn the filter in the direction of the arrow.

Warning: Beards in the sealing area of the mask can cause leaks. Always make sure the mask forms a tight seal and the filter is attached prior to entering a hazardous atmosphere. This poster is not a replacement for reading and understanding the instructions for use for the subject mask and respective filter cartridge, both of which must be read before using either item! Failure to do so could result in sickness or death! For further assistance concerning proper use, ask your supervisor or call your local Dräger organization at +1 800 922 5518.

Donning the mask



3 Place bottom straps over your head. With the Dräger X-plore 3500 first connect the hooks on the neck strap (inset figure).



4 Position facepiece over the mouth and nose and pull the head cradle over the head.



5 Pull the straps uniformly until the half-mask fits securely and comfortably against your face. If necessary readjust the straps.

Performing seal checks: before every use!



6 Negative pressure test: Seal both respiratory filters with your hands and breathe in until a negative pressure (suction) is generated. Hold your breath for a moment. The negative pressure should be maintained. If not readjust the face piece and adjust the straps or use a different size of mask. Repeat test until a successful seal check is met.



7 Positive pressure test: Seal the exhalation valve of half mask and exhale. The half mask will inflate slightly. If the exhaled air leaks out of the mask, readjust the face piece and adjust the straps or use a different mask size. Repeat test until a successful seal check is met.



8 Ready for use.

Distributed by
AFC International Inc
PO Box 894
DeMotte IN 46310
800.952.3293 • 219.987.6825
fax 219.987.6826
sales@afintl.com • www.afintl.com